



# WIRELESS CAMERA SCANNER (PALM TYPE)

## Specification:

Item NO.	WCS-99X
ISM Band	900MHz ~2520MHz
Switcher	Auto / Manual
Antenna	SMA
Battery Working Time	3Hrs approx. (Depent monitor on)
Power Input	DC 5V , 650mA(MAX) or AA Battery DC 1.5V x4
Video Display	2.5" Color TFT Monitor
Frequency Display	LCM
Auto Scan	20 sec/Per Cycle(H)-10 sec/Per Cycle(MH,M,ML,L)
Manual Scan	Once:1MHz/sec , Fastforward:10MHz/sec
Dimension	120(L) x 74(W) x 35(H)mm
Weight	240g

## Wireless Camera Scanner:



## How to operate:

### (1) Function adjust

- After the power switch to ON , to press smart key to 3 sec later and then unlock.
- Option function and to use smart key upper and lower fine tuning.(To adjust when the icon blinking.)
- To press smart key to 3 sec can finish all settlement.

Capture moving picture		Sensitivity icon		Warning indicator	
2	2 sec	L	-20dBm	ON	OPEN
		ML	-30dBm		
4	4 sec	M	-40dBm	OFF	CLOSE
		MH	-50dBm		
8	8 sec	H	-60dBm		

### (2) When scan the video signal , push the smart key to lock.

## Wireless Camera Scanner Include:

- Camera Scanner .....1pcs
- SMA Antenna.....2pcs
- Adaptor (DC 5V).....1pcs
- Alarm Terminal.....1pcs
- Instruction manual.....1copy

## Dimensions:

